




# FTXP20-35N9

THE " → " MARK SHOWS THE PIPING DIRECTION.

## REQUIRED SPACE FOR SERVICE AND VENTILATION





### SIGNAL TRANSMITTER



### BLADE ANGLE

UP/DOWN (AUTOMATIC)



WIRELESS REMOTE CONTROL  
(ARC480A78)

STANDARD LOCATION OF HOLES IN THE WALL

3D144255